
How To Start A Lawn Mowing Business

*How To Start
A Lawn
Mowing
Business*

*Downloaded from
www.everybodystreet.com
by Mayra & Leblanc*

INTRODUCTION: WHY KNOWING HOW TO START A LAWN MOWER CORRECTLY MATTERS

There is something deeply satisfying about a freshly mowed lawn. The crisp lines, the clean scent of cut grass, and the sense of order it brings to your property can set the tone for the entire weekend. But before you can achieve that manicured look, you have to confront the machine itself. If you have ever stood in

your garage, yanking a pull cord until your arm aches, or staring at a battery-powered mower that refuses to hum to life, you know that **how to start a lawn mower** is not always as simple as it sounds.

Many homeowners skip over the basics, only to find themselves frustrated when the engine sputters, coughs, or remains stubbornly silent.

Understanding the correct starting procedure is not just about saving time; it is about safety, engine longevity, and getting the most out of your

equipment. A mower that is started improperly can suffer from flooded engines, damaged spark plugs, or even dangerous kickback. Whether you are a first-time homeowner or a seasoned gardener who just bought a new model, mastering the art of starting your mower will make every lawn care session smoother and more enjoyable. In this guide, we will walk you through every step, from pre-start checks to troubleshooting, so you never have to push a silent mower back to the shed again.

**SAFETY FIRST:
WHAT TO DO
BEFORE YOU EVEN
TOUCH THE
STARTER**

Before you even think about turning a key or

pulling a cord, you must ensure the environment and the machine are ready. Safety is the foundation of **how to start a lawn mower** correctly. Take a moment to inspect the area where you will be working. Clear the lawn of any rocks, sticks, toys, or debris that could become dangerous projectiles when the blades engage.

Personal Protective Equipment

While it might seem like overkill for a simple chore, wearing

the right gear can prevent serious injury. Sturdy closed-toe shoes with good grip are non-negotiable. Safety glasses protect your eyes from flying debris, and hearing protection is a wise choice, especially if you are using a gas-powered model. Avoid loose clothing that could get caught in the moving parts, and tie back long hair.

Fuel and Oil Check

For gas mowers, check the oil level using the dipstick before every use. Running a mower on low oil can cause catastrophic engine damage within minutes. Also, inspect the fuel tank. If you are using old gasoline that has been sitting for

more than 30 days, it may have degraded and could cause starting problems. Fresh fuel is key to a reliable start. For electric mowers, ensure the battery is fully charged and the connections are clean and secure.

Inspect the Mower Deck and Blades

Look underneath the mower deck. Grass clippings, mud, and debris can clog the blade housing and make starting more difficult. A clean deck allows the engine to spin freely. Also, check

that the blade is not bent or damaged, as this can cause excessive vibration and strain on the starter system.

HOW TO START A LAWN MOWER: GAS-POWERED PUSH MOWERS

Gas-powered push mowers are the most common type found in suburban garages, and they also tend to be the most finicky. There are a few variations depending on whether your mower has a primer bulb, a choke, or an electric start. Let us break down the universal steps.

Step 1: Position

the Mower on a Flat Surface

Move the mower to a level area of your lawn or driveway. Never attempt to start a mower on a steep slope or inside a closed garage. Carbon monoxide from gas engines is deadly, and starting on a slope can cause the mower to tip or roll unexpectedly.

Step 2: Engage the

Safety e)

Features

Most modern mowers have a safety lever or bail that must be held against the handlebar for the engine to run. This is a critical safety feature. Make sure you understand how to squeeze this lever before you attempt to start. If the mower has a blade brake, ensure it is disengaged.

Step 3: Prime the Engine (If Applicable)

Look for a small rubber bulb, usually located near the carburetor or air filter cover. This is the primer bulb. Press it gently three to five times to push fuel into the carburetor. You should see fuel moving inside the bulb. Be careful not to over-prime, as this can flood the engine. If your mower does not have a primer bulb, it may have an automatic choke or a manual choke lever.

Step 4: Set the Choke

If your mower has a choke lever or flap, set it to the closed or full choke position when

the engine is cold. This restricts airflow and enriches the fuel mixture, making it easier to start. Once the engine warms up, you will need to gradually open the choke. Some mowers have a combination throttle and choke control; consult your owner's manual for the exact position.

Step 5: Pull the Starter Cord

Stand behind the mower with your feet shoulder-width apart. Hold the handlebar firmly with one hand and grasp the starter cord handle with the other. Pull the cord

slowly until you feel resistance, then give a smooth, strong, and steady pull. Do not yank it violently or let it snap back. Allow the cord to rewind gently. It may take two to four pulls for a cold engine to fire. If it does not start after several pulls, move on to the troubleshooting section.

Step 6: Adjust the Choke and Warm Up

Once the engine sputters to life, gradually move the

choke lever to the open position. Let the engine run for at least 30 seconds to a minute before you begin mowing. This allows the oil to circulate and the engine to reach operating temperature. Rev the engine briefly to ensure it runs smoothly before engaging the blade.

HOW TO START A LAWN MOWER: ELECTRIC AND BATTERY- POWERED MODELS

Electric mowers, both corded and battery-powered, have become increasingly popular due to their quiet operation and low maintenance. The starting procedure is generally simpler, but there are still important nuances to understand.

Starting a Corded Electric Mower

Plug the mower into a grounded outdoor extension cord that is rated for the amperage of the mower. Make sure the cord is positioned so that it trails behind you and will not be run over. Most corded mowers have a safety key or button that must be inserted or pressed before the start lever engages. Squeeze the bail handle, and the mower should start instantly. Always unplug the mower before clearing clogs or performing maintenance.

Starting a Battery-Powered Mower

Battery mowers require a fully charged battery pack. Insert the battery into the compartment until it clicks into place. Press the safety start button (if equipped) and then squeeze the bail handle. The mower should come to life with a quiet hum. If the mower does not start, check that the battery is properly seated and that the contacts are clean. Some models also require you to hold the start button for a second or two before the motor engages.

TROUBLESHOOTING COMMON STARTING ISSUES

Even when you follow every step correctly, things can go wrong. Knowing how to diagnose common problems will save you time and frustration. Here are the most frequent issues and how to resolve them.

The Engine Cranks but Will Not Start

This is the most common complaint. If you hear the engine turning over but it refuses to fire, the problem is usually fuel

or spark related. Check that you have fresh fuel in the tank. If the fuel is old, drain it and replace it. Next, inspect the spark plug. Remove the spark plug wire and use a spark plug socket to remove the plug. Look for carbon buildup or a cracked insulator. Clean the plug with a wire brush or replace it if necessary. Check the gap with a feeler gauge and adjust it to the manufacturer's specification.

The Engine Floods

If you smell gasoline strongly, you may have flooded the engine by over-priming. In this case, set the choke to

the open position and hold the throttle wide open (if applicable). Pull the starter cord several times with the choke off to clear the excess fuel. Let the mower sit for 15 minutes before trying again.

The Starter Cord Is Hard to Pull

A stiff pull cord can indicate a seized engine, a bent blade, or a problem with the recoil starter. First, try removing the spark plug and pulling the cord. If it pulls easily, the issue is internal compression or a

hydraulic lock in the cylinder. If it remains stiff, check the blade for obstructions or damage. If the blade spins freely but the cord is still hard to pull, the recoil assembly may need lubrication or replacement.

charged and that the charger is functioning properly. If the mower still does not start, consult the manufacturer's troubleshooting guide, as some models have internal fuses that may need replacement.

Battery-Powered Mower Will Not Start

For battery mowers, the most common culprits are a dead battery or a poor connection. Try a different battery if you have one. Clean the battery terminals with a dry cloth. Check that the battery is fully

SEASONAL MAINTENANCE FOR RELIABLE STARTING

One of the best ways to ensure you never struggle with **how to start a lawn mower** is to perform routine maintenance. A well-cared-for mower will start reliably every time.

End-of-Season

Storage

At the end of the mowing season, drain the fuel tank or add a fuel stabilizer. Run the mower until the carburetor is empty. Change the oil, clean or replace the air filter, and sharpen the blade. Store the mower in a dry, sheltered location. These steps prevent gummed-up carburetors and corroded components.

Pre-Season Tune-Up

Before the first mow of the year, check the oil, install a fresh spark plug, and replace the air filter if it is dirty. Inspect the fuel lines for cracks. A tune-up

takes less than an hour and can eliminate starting problems for the entire season.

Regular Cleaning

After each use, remove grass clippings from the undercarriage and around the engine. A clean mower runs cooler and starts more easily. Use a hose or a scraper to remove buildup, but avoid spraying water directly into the engine or air intake.

HOW TO START A LAWN MOWER: RIDING MOWERS AND TRACTORS

Riding mowers and lawn tractors follow a similar logic to push mowers, but with additional steps.

Always sit in the operator's seat before attempting to start. Most riding mowers have a safety switch that prevents starting unless the parking brake is engaged and the blades are disengaged. Insert the key and turn it to the run position. Set the choke if the engine is cold. Press the brake pedal and turn the key to start. Release the key once the engine runs. Gradually close the choke as the engine warms up. If your riding mower has a battery, ensure it is charged, as a weak battery is a common cause of starting failure in these machines.

CONCLUSION: MASTER THE START, ENJOY THE

CUT

Learning **how to start a lawn mower** properly is a small investment of time that pays dividends all season long. By following a consistent routine, checking your fuel and oil, and understanding the unique requirements of your specific model, you can eliminate the frustration of a stubborn engine. Remember that safety is always the first step, and regular maintenance is the secret to reliable performance. Whether you are pushing a gas mower across a small city lot or riding a tractor over several acres, a smooth start leads to a clean cut and a more enjoyable lawn care experience. Now, go ahead and

give that cord a pull with confidence.