
How To Descale A Keurig

*How To
Descale A
Keurig*

*Downloaded from
www.everybodystreet.com
by Swanson & Deshawn*

WHY YOUR KEURIG NEEDS REGULAR DESCALING

If you are a devoted coffee drinker, your Keurig brewer is likely one of the most-used appliances in your kitchen. It delivers a fresh cup of coffee in under a minute, but this convenience comes with a hidden cost: mineral buildup. Over time, calcium and limescale deposits from your water accumulate inside the machine. These deposits clog internal tubes, slow down

brewing, and can even ruin the taste of your coffee. Learning **how to descale a Keurig** is not just a maintenance task; it is essential for extending the life of your brewer and ensuring every cup tastes as rich and fresh as the first one you brewed. Descaling removes these stubborn mineral deposits, restores water flow, and keeps your machine running at peak performance.

WHAT HAPPENS IF YOU SKIP DESCALING?

Many owners ignore the descaling process,

often because they do not realize its importance. When you skip descaling, several problems begin to develop. First, your coffee starts brewing at a lower temperature because the heating element is coated with scale. Second, the brew time increases noticeably, sometimes taking twice as long to produce a single cup. Third, you may hear strange gurgling or sputtering noises as the machine struggles to push water through the clogged lines. Finally, the most obvious sign is a white, flaky residue appearing in your mug or on the splash guard. These symptoms all point to one solution: it is time to learn **how to descale a Keurig** properly.

HOW OFTEN SHOULD YOU DESCALE YOUR KEURIG?

The frequency of descaling depends heavily on your water hardness and how often you use the machine. Keurig officially recommends descaling every three to six months. If you live in an area with hard water, you will need to descale more frequently, possibly every two to three months. If you use filtered or distilled water, you can stretch the interval to six months. A good rule of thumb is to descale when you notice the "Descale" light illuminating on your machine, or when you observe any of the performance issues mentioned above.

Marking a reminder on your calendar every quarter is a simple way to stay consistent with this critical maintenance step.

WHAT YOU WILL NEED TO DESCALE YOUR KEURIG

Before you begin the descaling process, gather the following supplies. Having everything ready beforehand makes the task much smoother and faster.

- **Keurig Descaling**

Solution: Keurig sells its own branded solution, which is specifically formulated to dissolve limescale safely. This is the recommended choice.

- **White Vinegar:**

If you do not have the official solution, white distilled vinegar is a common household alternative. It works well but leaves a distinct vinegar smell that requires thorough rinsing.

- **Fresh Water:**

You will need a large amount of fresh water for the descaling cycle and for the multiple rinse cycles afterward.

- **A Large Mug or Carafe:**

You need a container that holds at least 12 ounces to catch the water as it dispenses.

- **Access to a Sink:**

Some parts will need

rinsing, and you will be emptying the water reservoir multiple times.

METHOD 1: USING KEURIG DESCALING SOLUTION (RECOMMENDED)

Using the official Keurig descaling solution is the safest and most effective way to clean your machine. It is specifically designed to not damage internal components and leaves no lingering odor or taste. Follow these steps carefully.

Step 1: Prepare

the Machine

Turn off and unplug your Keurig brewer. Remove the water reservoir, take off the lid, and wash it with warm soapy water. Rinse it thoroughly and set it aside to dry. Remove any pods from the pod holder. If your machine has a reusable filter, take it out and rinse it clean.

Step 2: Fill the Reservoir with

Descaling Cycle Solution

Empty the entire bottle of Keurig descaling solution into the water reservoir. Then, fill the empty solution bottle with fresh water and pour that into the reservoir as well. This creates the correct dilution ratio. If your reservoir is large enough, you can simply add water to the fill line indicated in your user manual.

Step 3: Run the Descaling

Plug the machine back in and turn it on. Place a large mug on the drip tray. Lift and lower the handle without inserting a pod. Select the largest brew size available on your machine (usually 10 or 12 ounces). Press the brew button. The machine will dispense hot water mixed with the descaling solution into your mug. Pour the contents of the mug into the sink. Repeat this process until the "Add Water" light turns on, indicating the reservoir is empty. Do not drink this liquid.

Step 4:

Let the Machine Sit

Once the reservoir is empty, turn off the machine. Allow the machine to sit for at least 30 minutes to allow the solution to work on internal scale deposits. For heavy buildup, letting it sit for an hour is even more effective.

Step 5: Rinse

Thoroughly

Remove the water reservoir and rinse it very well with fresh

water. Fill it completely with fresh, clean water. Reattach it to the machine. Run the entire brewing cycle again with fresh water, discarding each cup. You will need to refill and run the cycle multiple times until you have used at least one full reservoir of fresh water. This rinses away any remaining descaling solution from the internal lines.

Step 6: Wipe and Reset

Wipe down the exterior of the machine with a damp cloth. Clean the drip tray. If your machine has a "Descale" light, it should now be off. Your Keurig is now ready to

brew fresh, great-tasting coffee again.

METHOD 2: USING WHITE VINEGAR AS AN ALTERNATIVE

If you do not have access to the official solution, white vinegar is an effective alternative. However, it requires extra rinsing to remove the vinegar smell and taste. Here is how to descale a Keurig with vinegar.

Step 1: Create a Vinegar Solution

Mix equal parts white distilled vinegar and water. For most machines, this means filling the reservoir

halfway with vinegar and then topping it off with water. A 50/50 ratio is effective and safe.

Step 2: Run the Vinegar Solution

Follow the same process as the official solution. Place a mug on the drip tray, lift the handle, and run a brew cycle without a pod. Discard the liquid. Continue running cycles until the reservoir is empty.

Step 3:

Let It Soak

Turn off the machine and let the vinegar solution sit inside the internal lines for 30 to 45 minutes. This gives the acetic acid time to break down tough mineral deposits.

Step 4: Rinse, Rinse, and Rinse Again

This step is critical when using vinegar. After the soak, empty the reservoir and rinse it thoroughly. Fill it with fresh water. Run

multiple complete cycles with fresh water. You should plan to run at least three full reservoirs of fresh water through the machine to eliminate the vinegar smell and taste. If you still detect vinegar, run another full cycle.

Step 5: Final Clean

Wash the removable parts one more time. Brew a cup of plain hot water and check for any lingering odor. Once the water smells and tastes clean, your machine is ready for coffee.

HOW TO DESCALE SPECIFIC KEURIG

MODELS

While the general steps above work for most models, some Keurig machines have slight differences. Here are the adjustments for the most common series.

Keurig K-Mini and K-Mini Plus

These compact brewers do not have a removable water reservoir. To descale them, you pour the descaling solution directly into the water intake on the top of the machine. Follow the standard amount of solution and water. You will need to use a smaller mug because

the water tank holds less volume. The rinse process works the same way, using fresh water poured into the same intake.

Keurig K-Elite and K-Classic

These larger models have a removable water reservoir, which makes the process straightforward. They also have a "Descale" button or indicator light. When the light is on, it means the machine has detected a need for cleaning. After completing the descaling process, the light will turn off automatically. These machines also have a "Strong Brew" setting; you do not need to use

COMMON descaling. Use the regular brew size.

Keurig K-Cafe and K-Duo

These models are designed for specialty drinks. Before descaling, remove the milk frother or carafe and clean them separately according to the manual. The descaling process for the brewing unit is the same as the K-Elite. If your K-Duo has a carafe side, you will need to run the descaling solution through the carafe brew cycle as well. Consult your user manual for specific carafe descaling instructions.

MISTAKES TO AVOID WHEN DESCALING

Many users accidentally damage their Keurig or reduce its lifespan by making these common errors. Avoid them to keep your brewer in top condition.

- **Using too much vinegar:** A 50/50 ratio is plenty. Using pure vinegar is too acidic and can damage rubber seals and internal plastic components.
- **Skipping the rinse cycle:** This is the most common mistake. Residual descaling solution or vinegar will ruin

the taste of your coffee and may cause digestive discomfort. Always rinse thoroughly.

- **Descaling with a pod in the machine:** Never insert a coffee pod during descaling. The solution is only for cleaning, not for brewing.
- **Forgetting to remove the water filter:** If your Keurig has a charcoal water filter, remove it before descaling. The descaling solution will destroy the filter and release carbon particles into your machine.
- **Ignoring the exterior:** While internal cleaning

is vital, food-grade mineral buildup can also collect around the needle and pod holder. Wipe these areas clean with a damp cloth while you have the machine open.

ADDITIONAL TIPS FOR MAINTAINING YOUR KEURIG

Beyond regular descaling, there are other simple habits that will extend the life of your brewer and improve your coffee quality.

1. **Use filtered water:** Starting with water that has fewer minerals reduces scale buildup significantly. This means you can descale less

- frequently.
2. **Clean the needle regularly:** The entrance and exit needles can clog with coffee grounds. Use a paperclip or the cleaning tool that came with your machine to clear any blockages every few weeks.
 3. **Wash the drip tray and pod holder weekly:** These parts collect old coffee and bacteria. A quick wash with soap and water keeps your machine hygienic.
 4. **Replace the water filter:** If your model uses a filter, replace it every two months. This improves water quality and reduces scale.
 5. **Run a water-only cycle daily:** If you use your Keurig infrequently, run a cup of plain water through it before brewing to flush out any stagnant water.

SIGNS YOUR KEURIG NEEDS DESCALING IMMEDIATELY

Sometimes, you may forget to descale on schedule. Watch for these urgent signs that indicate your machine needs cleaning right away.

- The "Descale" light is flashing or glowing steadily.
- The machine makes loud popping or

hissing sounds during brewing.

- The coffee tastes flat, bitter, or metallic.
- The brewing cycle takes over two minutes to finish.
- You see visible white flakes in your coffee cup.
- The machine shuts off mid-brew or fails to heat water.

If you notice any of these issues, stop using the machine and descale it immediately. Ignoring them can lead to permanent damage that requires costly repairs or a replacement brewer.

FREQUENTLY ASKED QUESTIONS ABOUT DESCALING

Can I use lemon juice instead of vinegar?

Lemon juice is more acidic than vinegar and can damage internal parts. It is not recommended. Stick with Keurig solution or white vinegar.

Can I descale with the water

filter
installed?

No. Always remove the
water filter