

---

# How To Print On Fabric At Home

---

*How To Print  
On Fabric At  
Home*

*Downloaded from  
[www.everybodystreet.com](http://www.everybodystreet.com)  
by Callahan & Kailey*

---

## INTRODUCTION: THE WORLD OF FABRIC PRINTING

---

Have you ever looked at a plain t-shirt, a blank tote bag, or a simple piece of cotton and imagined it transformed? The ability to print on fabric opens up a world of creative possibilities, from personalized gifts and custom clothing to unique home decor and small business merchandise. Learning **how to print on fabric** is a valuable skill that combines artistry with practical

technique.

The journey from a digital design to a tangible, wearable piece of art might seem daunting, but it is more accessible than ever. With the right materials and a clear understanding of the processes, anyone can create professional-looking results. Whether you are a DIY enthusiast, an artist looking to reproduce your work, or an entrepreneur aiming to launch a product line, mastering fabric printing allows you to bring your visions to life directly onto textiles. This guide will

walk you through the most popular and effective methods, providing the knowledge you need to choose the perfect technique for your next project.

---

## **UNDERSTANDING THE BASICS OF FABRIC PRINTING**

---

Before diving into specific methods, it is crucial to understand the fundamental factors that influence a successful print. The type of fabric you choose, the ink or paint you use, and the preparation of your material all play a pivotal role. Different fabrics have different properties. A tight-weave cotton behaves very differently from a stretchy polyester blend or a delicate silk. The fiber content dictates which printing

method will adhere best and last longest.

Furthermore, consider the intended use of your project. A decorative pillow will have different durability requirements than a frequently washed t-shirt. Understanding these basics ensures you select the right approach, saving you time, money, and frustration. Preparing your fabric by washing it first to remove any sizing, starch, or finishes is a critical first step for most printing methods. This allows the ink or paint to bond directly with the fibers rather than a surface coating, leading to a more vibrant and permanent result.

---

## **METHOD 1: INKJET PRINTING WITH**

---

## **FREEZER PAPER**

For beginners or those looking for a quick, low-cost option, using a standard inkjet printer is an excellent starting point. This method is fantastic for printing detailed images, photographs, and intricate text onto lightweight fabrics like cotton, muslin, or linen. It requires no special equipment beyond your home printer, a sheet of freezer paper, and a pair of scissors or a rotary cutter.

## Step-by-Step Process

1. **Prepare Your Fabric:** Wash, dry, and iron your fabric to

ensure it is smooth and free of wrinkles. Cut a piece slightly larger than a standard 8.5 x 11 inch sheet of paper.

2. **Adhere the Fabric to the Paper:** Cut a piece of freezer paper to the same size as your printer paper. Place the **shiny side** of the freezer paper against the **wrong side** (the back) of your fabric. Iron them together on a medium-high setting (without steam). The heat will temporarily bond the fabric to the paper, creating a stiff, paper-like sheet that can pass

through your printer.

3. **Print Your**

**Design:** Set your printer to a standard paper setting (do not use a specialty or thick paper setting unless your design requires it for color quality). Load your fabric-paper sheet into the printer tray, ensuring it is oriented correctly for printable side up. Print your image using **pigment-based inks** if possible, as they are more wash-resistant than dye-based inks.

4. **Set the Ink:**

Immediately after printing, carefully peel the fabric from the

freezer paper. To make the design permanent, you need to heat-set it. Place a pressing cloth (like a thin cotton pillowcase) over the printed area and iron it on the highest heat setting your fabric can withstand for 3-5 minutes. Move the iron constantly to avoid scorching.

5. **Wash and**

**Enjoy:** Wait 24-48 hours before washing to allow the ink to fully cure. When washing, use a gentle cycle with cold water and mild detergent. Air drying is recommended for the first few

washes.

This technique is superb for small projects like fabric labels, art quilts, or custom patches. However, keep in mind that the print may have a slightly stiff texture initially, which softens after washing.

---

## **METHOD 2: SCREEN PRINTING FOR REPEATED DESIGNS**

---

Screen printing is the industry standard for creating high-quality, durable prints on fabric, especially for multiple copies of the same design. While it requires a bit more setup and specific equipment, the results are professional and long-lasting. This method works exceptionally well on t-shirts, tote bags, and

other apparel.

# Gathering Your Equipment

To get started with screen printing at home, you will need a few key items: a screen (a frame with a fine mesh), a squeegee, screen printing ink (water-based or plastisol), and a design stencil. Creating the stencil involves coating the screen with a photosensitive emulsion, exposing it to light with your design, and then washing out the unexposed areas.

# The Printing Process

1. **Set Up Your Station:** Secure your clean, dry fabric flat on a work surface. Tape down the edges to prevent shifting. Place your screen on top of the fabric with the design area positioned correctly.
2. **Apply the Ink:** Scoop a line of ink along the top edge of the design area on the screen.
3. **Flood the Screen:** Using the squeegee at a 45-degree angle, pull the ink across the screen once to fill the mesh. This is called flooding. Do this without pressing down hard.
4. **Printing Pass:** Now, make a second pass over the ink, this time applying firm, even pressure to push the ink through the mesh and onto the fabric beneath. Use a smooth, consistent motion.
5. **Lift and Cure:** Carefully lift the screen straight up. You will see your design on the fabric. The ink needs to be heat-set to become permanent. For water-based

inks, this is done with a heat press or a household iron for several minutes. Plastisol inks require a higher temperature, typically around 320-350°F (160-177°C).

Screen printing is ideal for bold, graphic designs and allows for layering different colors. While the initial setup requires practice, the ability to print the same design dozens or hundreds of times makes it incredibly efficient for small-batch production.

---

### **METHOD 3: SUBLIMATION PRINTING FOR VIBRANT ALL-OVER DESIGNS**

---

Sublimation printing is a specialized digital

method that produces stunning, photographic-quality prints that are embedded directly into the fibers of the fabric. Unlike inkjet or screen printing, which sit on top of the fabric, sublimation turns the ink into a gas that bonds with the polyester molecules under heat and pressure. This results in a print that is incredibly vibrant, soft to the touch, and will never crack, peel, or fade.

## Essential Requirements

- **Sublimation Printer & Ink:**  
You cannot use a regular inkjet

printer. You need a printer specifically converted for sublimation ink, or a dedicated sublimation printer.

- **Sublimation**

**Paper:** Special paper is required to hold the sublimation ink before it is transferred.

- **Polyester**

**Fabric or Coated Substrates:**

Sublimation only bonds with polyester or polymer-coated surfaces. Natural fibers like 100% cotton will not accept the dye. The fabric must be at least 50% polyester for a good result; 100% polyester

is best.

- **Heat Press:** A heat press is necessary to provide the consistent high heat and pressure needed for the sublimation process. A household iron rarely works well.

## The Process

1. **Print Your Design:** Print your mirrored (reverse) image onto the sublimation paper using your sublimation printer.
2. **Prepare Your Fabric:** Pre-press your fabric in the heat press



for a few seconds to remove moisture and wrinkles.

3. **Transfer:** Place your printed sublimation paper face down onto your fabric. Tape the edges to prevent shifting. Cover with a protective Teflon or parchment paper sheet.
4. **Press:** Apply the heat press at 400°F (200°C) for 45-60 seconds with medium to firm pressure.
5. **Peel and Reveal:** Remove the paper immediately or after a short cooling period, depending on the paper instructions. The

design will be permanently part of the fabric.

Sublimation is perfect for creating custom sportswear, flags, and all-over printed garments. Its durability and vibrancy are unmatched, but the limitation to polyester fabrics is a key consideration.

---

#### **METHOD 4: HEAT TRANSFER PAPER FOR QUICK AND EASY PROJECTS**

---

Heat transfer paper offers another simple, accessible way to print on fabric using a household inkjet or laser printer. It is essentially a two-step process: print onto the special paper, then apply it to the fabric with an iron or heat press. This method is excellent for small,

one-off projects and works on a wider variety of fabrics than sublimation, including 100% cotton.

## Types of Transfer Paper

- **Light Fabric Transfer Paper:**

Designed for white or very light-colored fabrics. The backing is usually transparent. The white areas of your design will remain clear or take on the fabric color.

- **Dark Fabric Transfer Paper:**

Designed for dark or colored fabrics. It has an

opaque white backing that covers the fabric color, making white and bright colors pop. You must cut around your design because the entire sheet transfers to the fabric.

## Step-by-Step Instructions

1. **Print a Mirrored Image:** Print your design in mirror (reverse) mode onto the transfer paper. If you are using a laser printer,

ensure you use laser-compatible paper.

2. **Trim Excess**

**Paper:** For dark fabric paper, carefully cut out your design as close to the edges as possible to avoid a visible film around your image.

3. **Pre-Heat**

**Fabric:** Pre-heat your iron to its highest setting (cotton setting, no steam). Pre-press your fabric for a few seconds to remove moisture.

4. **Apply Transfer:**

Place your printed transfer paper face down onto the fabric. Apply firm, even pressure with the iron for 30-45

seconds, moving in circles. A heat press is more effective but an iron works if you are thorough.

5. **Peel:** Allow the paper to cool completely (for some papers) or peel immediately (for others). Check your paper's instructions. Then, enjoy your new design.

Heat transfer paper is incredibly user-friendly but the prints can sometimes feel slightly plastic-like and may crack over time with repeated washing, especially compared to screen printing or sublimation.

---

## CHOOSING THE RIGHT FABRIC FOR

## **YOUR PROJECT**

---

The success of your fabric printing project heavily depends on selecting the correct fabric. As a general rule:

- **Cotton and Linen:** Excellent for inkjet printing with freezer paper, screen printing, and heat transfer paper. They are absorbent and hold detail well.
- **Polyester and Nylon:** Ideal for sublimation printing. They also work with screen printing using specific polyester-friendly