
How To Measure Wheel Offset

How To Measure Wheel Offset www.everybodystreet.com
by Reed & Hailey

Downloaded from

UNDERSTANDING THE BASICS OF WHEEL OFFSET

When upgrading or replacing wheels on a vehicle, few measurements matter more than wheel offset. This critical dimension determines how your wheels sit in relation to the wheel well and suspension components. Getting it wrong can lead to poor handling, premature tire wear, and even dangerous rubbing against the chassis.

Understanding how to measure wheel offset is essential for any DIY mechanic, car enthusiast, or professional installer. This guide will walk you through everything you need to know, from basic definitions to step-by-step measurement techniques, ensuring you select the perfect fitment for your vehicle.

WHAT EXACTLY IS WHEEL OFFSET?

Wheel offset refers to the distance between the wheel's mounting surface (where it bolts to the hub) and the

centerline of the wheel. Measured in millimeters, this figure determines how far inward or outward the wheel sits relative to the vehicle's suspension and bodywork. Offset directly influences steering response, stability, tire clearance, and overall appearance.

There are three primary types of offset:

- **Positive offset:** The mounting surface is located closer to the outside (street side) of the wheel, pushing the wheel inward toward the suspension. Most modern front-wheel-drive vehicles use positive offset wheels.
- **Negative offset:** The mounting surface sits closer to the inside (brake side) of the wheel, pushing the wheel outward from the

suspension. This is common on lifted trucks and off-road vehicles where a wider stance is desired.

- **Zero offset:** The mounting surface aligns exactly with the centerline of the wheel, meaning the wheel sits evenly on both sides of the hub.

Knowing how to measure wheel offset accurately allows you to determine whether a set of wheels will fit your vehicle without issues such as rubbing against the strut, fender, or control arm.

WHY WHEEL OFFSET MATTERS

Handling and Stability

Offset changes the scrub radius, which is the distance between the center of the tire contact patch and the steering axis. An improper offset can cause steering pull, excessive feedback through the wheel, and unpredictable behavior during braking or cornering. Correct offset maintains the engineered suspension geometry for safe, predictable handling.

Tire Clearance

Wheels with too much positive offset can contact brake calipers, suspension arms,

or the inner fender liner. Conversely, too much negative offset can cause the tire to protrude beyond the fender, leading to contact with the outer bodywork during compression or turning. Accurate measurement prevents these clearance problems.

Load Bearing and Wheel Bearing Life

Offset changes the lever arm acting on the wheel bearings. Excessive offset in either direction places additional stress on bearings, hubs, and suspension components, potentially leading to

premature failure. Keeping offsets within manufacturer specifications preserves component longevity.

Aesthetic Appearance

Wheel offset determines how flush a wheel sits with the fender. Enthusiasts often seek a specific stance, from tucked to aggressively flush. Measuring offset allows you to select wheels that achieve the desired look without compromising function or safety.

TOOLS YOU WILL NEED TO MEASURE WHEEL OFFSET

Before you begin, gather the following

items:

- A straight edge or ruler long enough to span across the wheel rim
- A tape measure or digital caliper capable of measuring in millimeters
- A flat surface such as a workbench or clean garage floor
- A wheel without a tire mounted, or a tire with low enough profile to access the rim edges
- Notepad and pen for recording measurements

For the most accurate results, use a bare wheel. If you must measure a wheel with a tire mounted, ensure the tire does not extend beyond the rim edge, as this will interfere with your straight edge.

STEP-BY-STEP GUIDE: HOW TO MEASURE WHEEL OFFSET

Step 1: Measure the Overall Wheel Width

Place the wheel face down on a flat surface with the back of the wheel facing upward. Lay your straight edge across the outer edges of the rim, ensuring it contacts both sides evenly. Use your tape measure or caliper to measure the distance from the straight edge down to the flat surface. This gives you the overall wheel width. Record this value in millimeters.

For example, if the measurement is 200 millimeters, that is the total width of the wheel from rim edge to rim edge.

Step 2: Calculate the Wheel Centerline

The centerline of the wheel is simply half of the overall width. Divide the overall width measurement by two. Using the example above, 200 millimeters divided by 2 equals 100 millimeters. This figure represents the centerline of the wheel.

Step 3: Measure the Backspace

With the wheel still face down and the back of the wheel upward, position your straight edge across the inner rim edges just as before. Now measure the distance from the straight edge down to the mounting surface, which is the flat area that contacts the hub. This distance is called the backspace. Measure carefully at the center of the mounting surface for the most accurate reading. Record this value in millimeters.

Suppose your backspace measurement is 130 millimeters.

Step 4: Calculate the Offset

Now you have all the numbers needed to calculate offset. Use this simple formula:

Offset = Backspace - Centerline

Using our example: 130 millimeters (backspace) minus 100 millimeters (centerline) equals 30 millimeters. This positive offset means the mounting surface is 30 millimeters outward from the centerline, which is typical for many front-wheel-drive vehicles.

If your backspace measurement is smaller than the centerline, your result will be a negative offset.

ALTERNATIVE METHOD:

Step 5: Verify Your Measurement

Repeat the process at least once to confirm accuracy. Even small errors in measuring backspace or overall width can lead to an incorrect offset value. If possible, compare your calculated offset against any markings stamped on the wheel. Many wheels have the offset printed on the back of one of the spokes, often indicated as "ET" followed by a number. For example, ET35 means an offset of 35 millimeters.

MEASURING OFFSET WITHOUT REMOVING THE WHEEL

In some situations, you may want to check offset on a wheel that is already mounted to the vehicle. While less precise, this method can give you a useful approximation.

1. Park the vehicle on a level surface and ensure the steering is straight.
2. Measure the total width of the wheel at the rim edges using a tape measure.
3. Measure from the hub face (the flat part of the wheel center) to the outer edge of the wheel on the fender side.
4. Subtract half the total width from this hub-to-outer-edge

measurement to estimate offset.

Keep in mind that this method introduces variables such as wheel hub thickness and dirt buildup. Always prioritize measuring a removed wheel for accuracy.

COMMON MISTAKES WHEN MEASURING WHEEL OFFSET

Confusing Offset with Backspace

These two terms are not interchangeable. Backspace is the distance from the mounting surface to the inner rim edge. Offset is the distance from the mounting surface to the

centerline. Understanding the difference is crucial for accurate measurement and proper wheel selection.

Measuring with a Tire Mounted

Tires that bulge beyond the rim edge prevent your straight edge from sitting flush against the rim. Always remove the tire or use a wheel that has a tire with a sidewall that is flush with or recessed from the rim edge.

Using Inches

Instead of Millimeters

Wheel offset is universally expressed in millimeters. If you measure in inches, convert your figures carefully (1 inch equals 25.4 millimeters). Even small conversion errors can result in selecting the wrong offset.

Assuming All Wheels Are

Stamped

While many wheels have the offset stamped on the back, this information can fade, wear off, or be inaccurate on aftermarket wheels. Always measure to confirm, especially when buying used wheels.

HOW OFFSET AFFECTS WHEEL FITMENT

Positive Offset Wheels

These are standard on most passenger cars. The wheel sits further inward, providing clearance for larger brake

components and allowing for a tighter turning radius. However, too much positive offset can cause the inner tire to rub against suspension parts, especially during full lock or under compression.

Negative Offset Wheels

Common in off-road and performance applications, negative offset pushes the wheel outward. This widens the vehicle's track, improving stability and allowing for larger tires. The trade-off includes increased stress on wheel bearings, potential fender rubbing, and a wider turning radius.

Zero Offset Wheels

Zero offset places the wheel evenly on both sides of the hub. This is rare on modern production vehicles but appears on some classic cars and certain aftermarket wheels. Zero offset offers a neutral position that can simplify fitment calculations.

PRACTICAL TIPS FOR SELECTING THE RIGHT OFFSET

- **Consult your vehicle's specifications:** Start with the factory offset and consider how much deviation your setup can

tolerate.

- **Account for tire width:** A wider tire with the same offset will sit closer to both the suspension and the fender. Adjust offset accordingly.
- **Test fit before committing:** If possible, mount one wheel and check clearance at full lock, full compression, and normal ride height.
- **Use spacers cautiously:** Wheel spacers effectively change offset. While they can correct minor fitment issues, they also place additional stress on hub components.
- **Consider adjustable suspension:** If you are running aftermarket coilovers or air ride,

offset requirements may differ from stock setups.

MEASURING WHEEL OFFSET FOR DIFFERENT VEHICLE TYPES

Passenger Cars

Most sedans, hatchbacks, and coupes use positive offsets ranging from ET35 to ET55. When measuring offset for these vehicles, pay close attention to brake caliper clearance, as larger aftermarket brakes may require lower offset wheels to fit.

Trucks and SUVs

Larger vehicles often accommodate a wider range of offsets. Stock offsets may be positive but less extreme than passenger cars. Off-road builds frequently use negative offset wheels to improve stability and allow for aggressive tire tread patterns. Measure carefully to ensure the tire does not contact the fender during articulation.

Performance and Sports Cars

These vehicles often have tight tolerances between the wheel, suspension, and bodywork. A small

change in offset can significantly impact handling characteristics. Always measure offset precisely and stay within a narrow range of the factory specification unless you are making coordinated changes to suspension geometry.

WHAT TO DO IF YOUR MEASURED OFFSET DIFFERS FROM FACTORY SPEC

If you measure a wheel that is currently on your vehicle and find the offset differs from the published factory value, consider the following possibilities:

- The previous owner may have installed aftermarket wheels or spacers.
- The wheel may have been

repaired or modified, altering its original dimensions.

- Your measurement may contain an error, so remeasure carefully.
- Some vehicles have different offsets for front and rear axles, especially performance models.

In any case, knowing the actual measured offset allows you to make informed decisions about replacements or upgrades.

FINAL THOUGHTS ON MEASURING WHEEL OFFSET

Mastering how to measure wheel offset empowers you to select wheels that fit correctly, perform optimally, and look

great. This straightforward measurement process requires only basic tools and a few minutes of time, yet it eliminates guesswork and prevents costly mistakes. Whether you are building a dedicated track car, upgrading your daily driver, or simply replacing worn wheels, understanding offset ensures you maintain safe handling, proper clearance, and long-term reliability. Take the time to measure accurately, verify your calculations, and always prioritize fitment that aligns with your vehicle's engineering. With this knowledge, you can confidently navigate the vast world of aftermarket wheels and achieve the perfect setup for your driving needs.