
How To Rebuild Your Small Block Chevy

*How To
Rebuild Your
Small Block
Chevy*

*Downloaded from
www.everybodystreet.com
by Cohen & Hinton*

INTRODUCTION: THE HEARTBEAT OF AMERICAN MUSCLE

There's a sound that every true gearhead recognizes instantly. It's the low, rumbling idle of a small block Chevy (SBC) firing to life for the first time after a painstaking rebuild. Whether you inherited a dusty 350 from your grandfather's garage, picked up a neglected project car, or simply want to breathe new life into your daily driver, learning **how to**

rebuild your small block Chevy is one of the most rewarding automotive projects you will ever undertake. It is a rite of passage, a masterclass in mechanical engineering, and a surefire way to save thousands of dollars while gaining intimate knowledge of your engine.

Contrary to popular belief, you do not need a professional machine shop to handle every aspect of the job. With the right tools, a clean workspace, and a methodical approach, the average DIY mechanic can

successfully complete an SBC rebuild. This guide will walk you through every critical stage, from the initial tear-down to the final break-in procedure. We will cover the essential steps, the common pitfalls, and the pro-tips that separate a successful rebuild from a frustrating failure. Let's get that Chevy running better than it ever has.

WHY REBUILD A SMALL BLOCK CHEVY?

Before we dive into the wrenching, it is important to understand the value of this iconic engine. The small block Chevy, in its various displacements from the 262 to the 400, has powered everything from Corvettes to farm trucks. Its ubiquity

means parts are cheap, readily available, and supported by an enormous aftermarket. Rebuilding your existing engine often makes more sense than buying a crate motor. A rebuild allows you to select specific components tailored to your driving style. Do you want a torquey stump-puller for towing? A high-revving street screamer for weekend cruises? An SBC rebuild gives you that freedom. Furthermore, you get the satisfaction of knowing every single nut, bolt, and gasket inside your powerplant is fresh and correctly torqued.

PHASE 1: PREPARATION AND DISASSEMBLY

The most critical part of any engine rebuild is

not the assembly; it is the preparation. Rushing this phase guarantees future headaches.

Gather Your Essential Tools

You cannot rebuild an engine with a single crescent wrench. You will need a comprehensive set of tools. At a minimum, invest in:

- A high-quality torque wrench (both ft-lbs and in-lbs).
- A complete set of sockets (standard and deep well) in SAE sizes.

- An engine hoist and a sturdy engine stand.
- A ring expander and a ring compressor.
- A micrometer and a dial bore gauge (or telescoping gauge) for measuring clearances.
- A good shop manual specific to your engine's year and model.

Documen t Everythin g

As you begin the teardown, **document everything**. Modern smartphones are your best friend here. Take

pictures of the accessory belt routing before you remove the alternator. Label every pushrod, rocker arm, and main bearing cap with a permanent marker or a labeled baggie. If you mix up the parts during disassembly, you will introduce wear patterns that can lead to premature failure. The small block Chevy is forgiving, but it is not magic.

Remove the intake manifold, cylinder heads, oil pan, and front timing cover. Once the short block is stripped to the bare block, remove the crankshaft, camshaft, and pistons. This is your last chance to inspect the block for cracks or fatal damage. If you see a rust hole in a water jacket or a crack between the

main bearing webs, you have found a candidate for a core charge at your local parts store, not a rebuild.

PHASE 2: THE MACHINE SHOP VISIT (CRITICAL STEP)

This is where the phrase **how to rebuild your small block Chevy** diverges from a simple parts-swapping exercise. Unless you own a milling machine, you cannot do this step yourself. You must take your block and rotating assembly to a professional machine shop.

Cleaning

and Inspection

The machine shop will hot-tank or chemically clean your block to remove 30 years of baked-on oil, grease, and rust. They will then magnaflux (magnetic particle inspection) the block to check for hairline cracks. A cracked block is scrap. A good block is then checked for deck flatness and main bearing bore alignment.

Boring and

Honing

Your cylinders are likely worn out of round. The machine shop will bore the cylinders oversize (typically 0.030" or 0.060") and then hone them to the exact finish required by your new piston rings. They will also align-hone the main bearing saddles to ensure the crankshaft spins perfectly true. Do not skip this step. Reusing old cylinder walls with new rings is a recipe for high oil consumption.

Resurfacing the

Cylinder Heads

Your cylinder heads need a fresh surface to seal properly. The machine shop will mill the head decks to ensure they are perfectly flat. They will also perform a three-angle valve job on the seats, grind the valves, and install new valve guides and seals. If your budget allows, consider a port and polish job to improve airflow. This is where you gain real horsepower.

PHASE 3: ASSEMBLY - PUTTING IT ALL TOGETHER

Now you have a clean, machined block and a box of new parts. This is the fun part. Work in

a very clean environment. Dust and dirt are your enemies. Wash the block again with soap and water even after the machine shop, and lubricate everything with clean engine oil or assembly lube as you go.

Installing the Crankshaft

Start with the crankshaft. Install the main bearing shells into the block and the main caps. Ensure the bearing tangs are correctly seated. Lubricate the bearings liberally with assembly lube. Set the crankshaft in place, install the main caps in

their correct orientation (all caps are numbered), and torque them to the factory specification. Check the crankshaft end-play with a feeler gauge; it should be between 0.002" and 0.006". If it's too tight or too loose, the thrust bearing is likely the wrong size.

Piston and Ring Installation

Before you install the pistons, you must gap the rings. This is a step many beginners skip. Using a ring file, file the ends of each ring until the gap between the ends, when placed in the cylinder bore,

meets the manufacturer's specification. Incorrect ring gaps can cause ring butting (scoring the cylinder) or excessive blow-by. Once gapped, install the rings on the pistons, staggering the ring gaps 120 degrees apart. Lubricate the cylinders and the piston skirts, compress the rings with a ring compressor, and tap the pistons into the bores. **Never force a piston.** If it does not slide in easily, something is wrong.

Timing the Camshaft

The camshaft controls the valve events. Install the cam

bearings (usually done by the machine shop), lubricate the cam lobes with special cam break-in lube (this is critical for flat-tappet cams), and slide the camshaft into the block. Install the timing chain and gears.

Degree the camshaft. Do not trust the dot-to-dot alignment method blindly. Use a degree wheel and a dial indicator to verify the intake centerline is correct. A cam that is installed 4 degrees retarded will feel flat and lazy. A cam that is advanced will have more bottom-end torque.

Installing

the Cylinder Heads and Valvetrain

Use new head gaskets of the correct thickness (copper, MLS, or composition, depending on your surface finish). Torque the head bolts in the manufacturer's specified sequence and torque values. Do not reuse old head bolts; they stretch. Install the pushrods, rocker arms, and rocker studs. Adjust the valve lash (for mechanical cams) or preload (for hydraulic cams)

precisely. A sloppy valvetrain is noisy and loses power.

PHASE 4: FINAL ASSEMBLY AND INSTALLATION

With the short block and heads complete, you can install the intake manifold, timing cover, oil pan, water pump, and harmonic balancer. Use a thin layer of RTV silicone at the corners of the intake manifold where it meets the china walls. Install the distributor, ensuring the rotor points to the number one cylinder tower on the cap when the engine is at top dead center.

Setting

Ignition Timing

Prime the oil system with a drill-driven primer tool before you install the distributor. This ensures all bearings have oil pressure before the engine ever fires. Install the distributor, set the initial timing to around 10-12 degrees before top dead center, and connect the plug wires in the correct firing order: 1-8-4-3-6-5-7-2.

PHASE 5: THE FIRST START AND BREAK-IN

This is the moment of truth. The procedure for breaking in a new camshaft is non-negotiable. Start the engine and immediately bring the

RPM to 2000-2500 RPM. Do not let it idle. You must run it at this elevated speed for 20 minutes. This is called the break-in cycle. It seats the cam lobes to the lifters. If you let a flat-tappet cam idle during break-in, you can wipe a lobe off in seconds. After the 20-minute cycle, change the oil and filter. You now have a fresh engine.

Break-In Driving

For the first 500 miles, vary the engine speed. Do not hold a constant RPM on the highway. Do not lug the engine. Do not rev it past 4000 RPM. Change the oil again at 500 miles, and then you are free to drive it normally. A proper break-in

extends engine life significantly.

COMMON MISTAKES TO AVOID WHEN REBUILDING AN SBC

Even experienced mechanics make errors. Here are the most common ones you should consciously avoid during your rebuild:

- **Neglecting the Cooling System:** A fresh engine run with a rusted, clogged radiator can overheat instantly. Flush or replace the radiator.
- **Using Cheap Gaskets:** Spend the money on Fel-Pro or OEM gaskets. Cheap gaskets leak.

- **Ignoring Lubrication:**
You cannot use too much assembly lube. Every contact surface needs it.
- **Skipping the Cam Degreeing:** As mentioned, this is where real performance is found or lost.
- **Hiding the Spark Plugs with the Valvetrain:**
Always check piston-to-valve clearance with clay before final assembly if you are using a large cam.

COST CONSIDERATIONS AND BUDGETING

A full rebuild of a small block Chevy is not cheap, but it is

significantly less expensive than a modern crate engine. Budget approximately:

- **Machine work:**
\$400 - \$800
(bore, hone, deck, valve job)
- **Pistons and rings:** \$200 - \$500
- **Bearings and gaskets:** \$150 - \$300
- **Camshaft and lifters:** \$150 - \$400
- **Oil pump and timing set:**
\$100 - \$200
- **Miscellaneous (bolts, seals, fluids):** \$150

Your total will likely fall between \$1,200 and \$2,500 for a solid street rebuild. Compare that to a \$5,000+ crate motor, and you see the value of doing the labor

yourself. Remember to factor in the cost of tools if you do not already own them.

CONCLUSION: THE PRIDE OF A JOB WELL DONE

Learning **how to rebuild your small block Chevy** is more

than just turning bolts. It is an exercise in patience, precision, and passion. When you twist the key and that engine catches the first time, the roar that echoes through your garage is a direct result of your own hard work and ingenuity. It is not just a motor