

---

# How To Use A Voltmeter

---

*How To Use A Voltmeter*

Downloaded from  
[www.everybodystreet.com](http://www.everybodystreet.com) by Jocelyn &  
Phillips

---

## INTRODUCTION

---

Whether you are a curious hobbyist, a student learning electronics, or a seasoned electrician, knowing **how to use a voltmeter** is a fundamental skill. A voltmeter is a simple yet powerful tool that measures the electrical potential difference between two points in a circuit. Understanding voltage is key to troubleshooting dead batteries, diagnosing faulty wiring, or verifying that a power supply is delivering the correct output. This guide will walk you through everything you need to know — from the different types of voltmeters to step-by-step measurement techniques — so you can confidently take accurate voltage readings every time.

---

## UNDERSTANDING VOLTMETERS

---

A voltmeter is designed to measure voltage, which is the force that pushes electrons through a conductor. The unit of measurement is the **volt (V)**. Most modern voltmeters are part of a **digital multimeter (DMM)** that can also measure current and resistance. However, there are also standalone analog voltmeters with a needle and scale. Regardless of the type, the core

principle of **measuring voltage** remains the same: the meter must be connected in **parallel** with the component or power source being tested.

## Analog vs. Digital Voltmeters

**Analog voltmeters** use a moving coil to deflect a needle across a printed scale. They are less common today but can be useful for observing rapid fluctuations in voltage because the needle responds in real time. **Digital voltmeters** display a numeric readout, offer greater precision, and usually include auto-ranging features. For most users, a digital multimeter (DMM) is the most practical and user-friendly choice for **how to use a voltmeter** in everyday situations.

## Key Features of a Digital

# Multimeter

- **Display screen** – Shows the measured value and often includes a bargraph.
- **Selection dial** – Lets you choose the type of measurement (voltage, current, resistance) and the range.
- **Input jacks** – Typically three ports: COM (common), VΩmA (voltage, resistance, and milliamps), and 10A (high current).
- **Test leads** – Red (positive) and black (negative) probes with insulated tips.
- **Range selection** – Auto-ranging meters select the correct range automatically; manual-range meters require you to set the expected maximum voltage.

---

## SAFETY FIRST WHEN USING A VOLTMETER

---

Before you connect any probes, safety should be your top priority. Electricity can be dangerous, so following these precautions ensures you **use a voltmeter** without risk of injury or damage to the meter.

1. **Check the meter's voltage rating.** Ensure your voltmeter is rated for the voltage you plan to measure. For household circuits (120V–240V AC), a CAT II or CAT III rated meter is appropriate.
2. **Inspect test leads.** Look for cracks, exposed wire, or damaged insulation. Never use damaged leads.
3. **Set the dial correctly.** Always start with a higher range

than your expected voltage to avoid overloading the meter.

4. **Connect the probes to the correct jacks.** For voltage measurement, the red lead goes into the VΩmA jack, and the black lead into the COM jack.
5. **Never measure voltage in a live circuit with the meter set to current or resistance mode.** This can blow a fuse or damage the meter.
6. **Work with one hand when possible** to reduce the risk of a shock path across your chest.

---

## STEP-BY-STEP: HOW TO USE A VOLTMETER

---

Let's walk through a typical scenario — measuring the voltage of a battery or a wall outlet. These instructions work for both analog and digital voltmeters, though the exact buttons and dials may vary.

## Step 1: Select the Voltage Type

Turn the dial to the appropriate voltage setting. Most meters have separate settings for **DC voltage (often marked with a V and a straight line or dashes)** and **AC voltage (V with a wavy line ~)**. For a car battery or AA battery, choose DC volts. For a household electrical outlet, choose AC volts.

## Step 2: Choose the Range (If Manual Ranging)

If your voltmeter is manual-ranging, select a voltage range higher than what you expect. For example, for a 12V car battery, choose the 20V DC range. For a 120V wall outlet, choose 200V or 600V AC range. If you select too low a range, the display may show “OL” (overload) or the needle will peg to the right. If the range is too high, you lose precision but still get a reading.

## Step 3: Insert the Test Leads

Plug the black lead into the **COM** jack (common/negative). Plug the red lead into the **VΩmA** jack (positive for voltage). Some meters also have a dedicated voltage jack; always follow the markings.

## Step 4: Connect the Probes in Parallel

To measure voltage, the voltmeter must be connected across the component or power source. Touch the black probe to the negative side (or ground) and the red probe to the positive side.

For a battery, touch black to the flat terminal (negative) and red to the raised terminal (positive). For an AC outlet, it doesn't matter which probe goes into which slot, but make sure the probes are fully inserted and you keep your fingers behind the guards.

## Step 5: Read the Measurement

Look at the display or the position of the needle. For a digital meter, the number is the voltage. For an analog meter, read the scale that matches your range setting. If the display shows a negative sign (for DC), you have the probes reversed — that's fine; simply swap them or note the absolute value.

## Step 6: Remove the Probes Safely

First, remove the red probe, then the black probe. Turn the dial to the “OFF” position to preserve battery life, and store the meter with the leads coiled neatly.

---

### COMMON APPLICATIONS AND MEASUREMENTS

---

Now that you know the basic steps, let's apply them to real-world tasks. Being able to **use a voltmeter** effectively opens up many possibilities.

## Testing Batteries

To check if a battery is still good, set the meter to DC volts and choose an appropriate range (2V for a 1.5V AAA, 20V for a 9V, etc.). Touch the probes to the terminals. A fresh 1.5V alkaline battery should read around 1.6V. Below 1.2V indicates it's nearly dead. For a 9V battery, above 8V is healthy; below 7V it's weak.

## Checking Wall Outlets

Set the meter to AC volts and a range of 200V or 600V. Insert the probes into the two vertical slots (neutral and hot). In North America, you should see between 110V and 120V. For a 240V outlet (like for a dryer), the reading will be around 240V. Always use extreme caution when working with household AC power.

## Diagnosing a Car Battery or Alternator

With the engine off, measure the battery voltage at the terminals (red to positive, black to negative). A healthy 12V lead-acid battery should read about 12.6V. Start the engine; the voltage should rise to 13.5V–14.5V if the alternator is charging correctly. This quick test can help you identify a dead battery or a faulty alternator.

## Measuring Voltage Drop in a Circuit

Voltage drop occurs when components or wires resist the flow of electricity. To measure it, place the probes across the component while the circuit is powered. For instance, to check a light bulb socket, touch one probe to the center contact and the other to the outer shell. A reading near the supply voltage means the socket is receiving power; a low reading indicates a poor connection.

---

### TROUBLESHOOTING TIPS AND COMMON MISTAKES

---

Even experienced users sometimes get odd readings. Here are tips to avoid errors when you **use a voltmeter**.

- **The meter reads zero or very low?** Make sure the probes are making good contact. For DC, confirm you are touching the correct terminals. For AC, ensure the outlet is live (try a known working device).
- **OL (overload) or the needle pegs?** You selected a range that is too low. Switch to a higher range or use auto-range if available.
- **Negative sign on DC reading?** Probes are reversed. This doesn't harm the meter; just swap probes or note the absolute value.
- **Reading fluctuates wildly?** This can happen with AC if there is noise in the line, or with DC if the circuit is

unstable. Try selecting a lower range for better stability, or use the hold function.

- **The meter doesn't turn on?** Check the internal battery. Most digital multimeters use a 9V battery that needs replacement periodically.
- **Measuring voltage in a circuit with power off?** You'll get zero, which is correct. Some circuits may have capacitors that hold a charge — discharge them safely before testing.

---

### ADVANCED TECHNIQUES: USING A VOLTMETER FOR TROUBLESHOOTING

---

Beyond simple measurements, a voltmeter is invaluable for systematic **electrical troubleshooting**. Here are two powerful methods.

## Comparing Voltage Readings Along a Circuit

If a device isn't working, measure the voltage at each connection point along the power path. For example, in a light string, start at the plug and work toward the socket. If you have voltage at the plug but nothing at the first socket, there is a break in the wire between them. This method isolates faults efficiently.

## Using a Voltmeter to Check Continuity (Indirectly)

While a voltmeter isn't a continuity tester, you can sometimes infer continuity by measuring voltage. If you place the probes across a closed switch, you should read near zero voltage (because there is little resistance). A high voltage reading across a switch indicates it is open (disconnected). That's not a direct test but can be helpful in live circuits.

---

### CHOOSING THE RIGHT VOLTMETER FOR YOUR NEEDS

---

If you're still selecting a voltmeter, consider these factors to make the best choice for **how you plan to use it**.

- **Accuracy and resolution:** For electronics, a meter with 4-digit display and 0.1mV resolution is helpful. For household work, a 3-digit display is fine.
- **Auto-ranging vs. manual:** Auto-ranging is more convenient; manual-ranging is cheaper and teaches you about scales.
- **Safety rating:** Look for CAT II or CAT III for residential use, CAT IV for utility work.
- **Extra features:** Backlight, hold button, true RMS for accurate AC readings with non-sine waveforms, and a continuity buzzer.

---

## **MAINTAINING YOUR VOLTMETER**