
Model 25 Daisy Bb Gun Repair Manual

*Model 25
Daisy Bb Gun
Repair
Manual*

*Downloaded from
www.everybodystreet.com
by Shelton & Raiden*

INTRODUCTION

For generations, the Daisy Model 25 has been a staple in American backyards and shooting ranges. Known for its lever-action design and reliable performance, this classic BB gun has introduced countless shooters to the joys of plinking and marksmanship. However, like any mechanical device, the Model 25 can experience wear and tear over decades of use. When the lever won't cock properly,

the seal leaks, or the BBs fail to feed, a proper **Model 25 Daisy BB Gun Repair Manual** becomes an essential tool. This article serves as a comprehensive guide for owners, collectors, and hobbyists who need to restore their beloved firearm to full working order. We will cover the most common issues, step-by-step repair procedures, parts identification, and maintenance tips—all based on the original factory manual and field-tested techniques. Whether you have inherited a dusty Model

25 from a relative or you are a seasoned enthusiast looking to preserve a piece of shooting history, understanding the inner workings of this airgun is vital. This guide is written for human readers, not search engines, so you can follow along with confidence. We will avoid unnecessary jargon, explain each repair clearly, and highlight safety precautions. By the end, you will know exactly how to source a genuine **Model 25 Daisy BB Gun Repair Manual** and perform the most common repairs yourself.

UNDERSTANDING THE DAISY MODEL 25

Before diving into repairs, it helps to know what makes the

Model 25 unique. Produced by Daisy Outdoor Products since the early 20th century, this lever-action BB gun uses a spring-piston mechanism to propel steel BBs. It is a non-PAL (non-powder actuated) firearm in most jurisdictions, but it still requires respect and safe handling. The gun is known for its distinctive long barrel, hardwood stock, and tubular magazine that holds up to 50 BBs. Over the years, several variants were produced, but the basic design remained remarkably consistent. This consistency means that a general **Model 25 Daisy BB Gun Repair Manual** applies to most models from the 1950s through the 1990s.

Common Components That Need Repair

The most frequent failures in the Model 25 involve three areas: the lever assembly, the piston cup (seal), and the feed mechanism. The lever can become loose due to worn pivot pins or bent linkage arms. The piston cup, made of leather or synthetic material, dries out and cracks over time, causing a loss of compression. The feed ramp or magazine spring can also fail, leading to jams or inability to load BBs. A comprehensive

repair manual will address each of these issues with diagrams and step-by-step instructions.

WHERE TO FIND AN AUTHENTIC REPAIR MANUAL

Daisy no longer prints paper manuals for the Model 25, but you can still obtain official documentation through several channels. The most reliable source is the Daisy website itself, which offers PDF downloads of vintage manuals under their "Support" or "Resources" section. Additionally, online forums such as the Daisy Collectors Forum and Airgun Depot often host scanned copies. When searching for a **Model 25 Daisy BB Gun Repair Manual**, be wary of third-party sellers offering

incomplete or poorly photocopied versions. Always look for the official Daisy logo and part numbers. If you prefer a physical copy, specialty bookstores and vintage gun parts dealers sometimes carry reprints.

Essential Information in the Manual

A proper manual will include an exploded parts diagram, a list of replacement part numbers, torque specifications for screws, and detailed instructions for disassembly and reassembly. It will also cover troubleshooting common problems like

"gun fires weakly" or "lever feels loose." Without this manual, you risk damaging the gun or creating a safety hazard. Therefore, securing an authentic **Model 25 Daisy BB Gun Repair Manual** is the first and most important step before starting any repair work.

TOOLS AND SUPPLIES NEEDED

Before you begin, gather the following tools and materials. Most are common household items:

- **Flathead and Phillips screwdrivers** (small to medium sizes)
- **Needle-nose pliers**
- **Punch set or small drift pin** (for removing roll

- pins)
- **Nylon or brass hammer** (to avoid damaging metal)
- **Gun oil or light machine oil** (e.g., 3-in-1 or Hoppe's)
- **Replacement piston cup** (available online from Daisy parts suppliers)
- **Leather or synthetic piston seal** (depending on model)
- **Spring compressor** (optional, but helpful for reassembly)
- **Safety glasses**

Many of these items are mentioned in the official **Model 25 Daisy BB Gun Repair Manual**. Having them on hand will streamline the process and

prevent frustration.

STEP-BY-STEP REPAIR: REPLACING THE PISTON CUP

One of the most common repairs is replacing a dried-out or broken piston cup. This repair restores compression and velocity. Follow these steps carefully, referring to your **Model 25 Daisy BB Gun Repair Manual** for specific screw locations and torque settings.

Step 1: Unload and Clear

the Gun

Ensure the gun is completely unloaded. Open the loading port and verify no BBs are in the magazine tube or chamber. Point the gun in a safe direction and cycle the lever several times to clear any stuck ammunition. Wear safety glasses throughout.

Step 2: Disassemble the Stock

Remove the stock by unscrewing the two long bolts that pass through the receiver. Typically, one is under the buttplate and the other near the wrist of

the stock. Keep the screws in a safe container. Slide the stock off rearward.

Step 3: Access the Piston Assembly

With the stock removed, you will see the main spring tube. Remove the trigger guard and trigger mechanism by prying out the retaining pin (refer to your manual for exact location). This exposes the spring and piston. Using a spring compressor or a sturdy clamp, compress the mainspring until you can safely slide out the retaining pin at the rear of the tube. Slowly release tension.

Step 4: Reassemble Replace the Piston Cup

Pull out the piston assembly. The cup is attached to the front of the piston. Remove the old cup by prying it off gently. Clean the piston face with a soft cloth. Install the new cup according to the manual's orientation (usually with the concave side facing the barrel). Ensure a snug fit. Apply a drop of oil to the inside of the cup to soften it.

Step 5:

Reverse the disassembly steps. Recompress the mainspring, insert the retaining pin, and slowly release the compressor. Reattach the trigger assembly and stock. Cycle the lever a few times to check smooth operation.

COMMON ISSUES AND TROUBLESHOOTING

Even with a genuine **Model 25 Daisy BB Gun Repair Manual**, you might encounter problems. Here are typical scenarios and solutions:

- **Gun won't fire at all:** Check the

lever linkage.
Often a bent or
slipped pin
prevents the sear
from engaging.
Open the
receiver and
inspect the
linkage against
the diagram.

- **BBs fail to**

load: The
magazine tube
may be dented
or the spring
weak. Straighten
the tube or
replace the
magazine spring.

- **Fires but very
low velocity:**

Almost always a
piston seal issue.
Replace as
described above.
Also check the
barrel for
obstructions.

- **Lever is loose:**

The pivot screws
may be loose or
the linkage worn.

Tighten screws
or replace
linkage pins.

Remember, the manual
provides specific part
numbers. If you need a
new mainspring, look
for OEM part 25-xxx.
Generic springs may
cause damage.

MAINTENANCE TIPS TO EXTEND LIFE

Preventive care is
cheaper than repairs.
After every few
hundred shots, do the
following, referencing
your **Model 25 Daisy
BB Gun Repair
Manual** for lubrication
points:

- **Oil the leather
piston cup** with
a few drops of
non-detergent oil
(never use
WD-40, it dries
out seals).
- **Clean the**

barrel with a soft patch rod. Avoid aggressive solvents.

- **Check screws** for tightness, especially those securing the stock and the rear sight.
- **Store the gun uncocked** to relieve tension on the mainspring.
- **Keep the magazine tube clean** by flushing with compressed air.

Following these simple steps will keep your Model 25 shooting straight for another lifetime.

SAFETY CONSIDERATIONS WHEN REPAIRING

Even though it is a BB gun, the Model 25

contains a powerful spring under high compression. Always use a spring compressor or a vice when working on the mainspring to avoid injury. Never point the gun at anyone during repair, even if you believe it is unloaded. Wear eye protection to guard against flying pins or spring parts. If you are uncertain about a step, consult your **Model 25 Daisy BB Gun Repair Manual** or seek advice from an experienced gunsmith. Remember, proper repairs maintain safety as well as function.

Legal Note

In some jurisdictions, modifying an airgun can change its legal

classification. Ensure your repairs keep the gun in original specification unless you have legal clearance. The manual's instructions are intended for maintenance and restoration, not conversion.

CONCLUSION

Knowing how to repair your Daisy Model 25 not only saves money but also preserves a piece of shooting heritage. A reliable **Model 25 Daisy BB Gun Repair Manual** is your best companion

for this journey. Whether you are fixing a broken lever, a worn seal, or a jammed feed mechanism, the steps outlined in this article—combined with the official manual—will give you the confidence to do the job right. Take your time, use the proper tools, and always prioritize safety. With a little patience and the right guidance, your Model 25 will be shooting accurately for another generation. Enjoy the satisfaction of bringing a classic back to life.