
How To Clean A Top Loader Washing Machine

How To Clean A Top Loader Washing Machine

Downloaded from
www.everybodystreet.com by Grant &
George

INTRODUCTION: WHY YOUR TOP LOADER DESERVES A DEEP CLEAN

Your washing machine works tirelessly to keep your clothes fresh, but over time, it can become a breeding ground for mold, mildew, and mineral deposits. If you've noticed a musty odor, grayish residue on your laundry, or even slower drainage, it's a clear sign that your machine needs attention. Knowing **how to clean a top loader washing machine** is not just about aesthetics—it's about maintaining appliance efficiency and preventing costly repairs. A clean machine also means cleaner clothes, free from bacteria and detergent buildup. This guide walks you through every step, from routine maintenance to a thorough deep clean, using common household items. By the end, you'll have the confidence to restore your washer to a like-new condition.

WHY REGULAR CLEANING MATTERS

The Hidden Dirt in Your Washer

Even though your washing machine handles soap and water daily, it traps dirt, lint, and detergent residue in places you can't see—under the agitator, inside the drain hose, and along the rim. Over time, this buildup creates a habitat for bacteria and mold. A 2019 study found that 60% of washing machines tested contained pathogenic bacteria. Learning **how to clean a top loader washing machine** monthly can reduce these risks.

Signs Your Top Loader Needs a Clean

- A persistent musty or sour smell after a wash cycle
- Visible mold or slime under the lid or around the detergent dispenser
- Clothes coming out with gray or white residue
- Slower drainage or water pooling after a cycle
- Excessive suds even with small amounts of detergent

If any of these sound familiar, it's time to roll up your sleeves.

PREPARING YOUR WASHING MACHINE FOR CLEANING

Safety First

Before you begin, unplug the machine or turn off the circuit breaker if the unit is hardwired. Wear rubber gloves, especially if you're using bleach or vinegar. Ensure the area is well-ventilated. This step is crucial when learning **how to clean a top loader washing machine** safely.

What You'll Need

- White distilled vinegar (at least 2 cups)
- Baking soda (1 cup)
- A microfiber cloth or soft sponge
- An old toothbrush or small scrub brush
- Bleach (optional, for heavy mold)
- A bucket or bowl
- Toothpicks or a small stick for crevices

STEP-BY-STEP: HOW TO CLEAN A TOP LOADER WASHING MACHINE

Step 1: Empty and Inspect

Remove any laundry or items from the drum. Check pockets for forgotten tissues or coins—they can clog the pump. Look inside the lint trap if your machine has one, and clean it out. Pull out the detergent and fabric softener dispensers (they often snap out) and set them aside for soaking.

Step 2: Clean the Dispensers and Exterior Parts

Soak the dispensers in warm water with a few drops of dish soap. Use a toothbrush to scrub away residue, especially in the small holes where liquid softener flows. Meanwhile, wipe down the machine's exterior with a damp cloth. Pay attention to the lid rim and hinges—mold often hides there. For stubborn spots, use a paste of baking soda and water. This step in **how to clean a top loader washing machine** ensures no cross-contamination from dirty dispensers.

Step 3: Tackle the Gaskets

and Lid Rim

Top loaders don't have rubber door gaskets like front loaders, but they do have a rubber seal around the lid and agitator. Use a toothbrush dipped in vinegar to scrub these areas. Look for black mold spots; if present, apply a small amount of bleach to the brush and scrub gently. Rinse with a damp cloth. Be thorough—this is a prime location for odor-causing buildup.

Step 4: The Vinegar Cycle (Deep Clean Phase 1)

Pour 2 cups of white vinegar directly into the drum. Set your machine to the largest load size, hottest water temperature, and longest wash cycle. Start the cycle and let it agitate for a few minutes, then pause it (if your machine allows) or stop the cycle for about 30–60 minutes. This allows the vinegar to soak into the grime, dissolving mineral deposits and soap scum. After soaking, resume and complete the cycle. The vinegar will also deodorize the machine naturally.

Step 5: The Baking Soda

Cycle (Deep Clean Phase 2)

Once the vinegar cycle finishes, sprinkle 1 cup of baking soda into the drum. Run another hot, full cycle, but this time pause it after agitation for 30 minutes as well. Baking soda is a mild abrasive that helps lift remaining residue and neutralizes any leftover vinegar smell. This two-step process is widely considered the most effective method for **how to clean a top loader washing machine** without harsh chemicals.

Step 6: Scrub the Agitator and Drum

While the machine is empty after the baking soda cycle, take a microfiber cloth or sponge and wipe down the inside of the drum, including the agitator. For top loaders with a center post, use a small brush to reach underneath the agitator where gunk hides. Some agitators can be removed (check your manual) for a deeper clean. If yours comes off, soak it in vinegar and water before scrubbing.

Step 7: Clean the Drain

Filter (If Accessible)

Not all top loaders have an accessible drain filter—some are hidden behind a small panel at the bottom front of the machine. Consult your user manual. If you can access it, place a towel underneath, unscrew the filter cap (be ready for water spillage), and pull out any lint, hair, or coins. Rinse the filter under running water and reinstall it tightly. This step is often overlooked but vital for proper drainage.

Step 8: Run a Final Rinse Cycle

To ensure no vinegar or baking soda residue remains, run a quick wash cycle with cold water (no detergent). This final rinse gives your machine a fresh start. Open the lid to let the drum air-dry completely before using it again.

MAINTENANCE TIPS TO KEEP YOUR TOP LOADER FRESH

Monthly Cleaning Routine

Repeat the vinegar and baking soda cycles every 4–6 weeks, especially if you live in an area with hard water or if your household does multiple loads daily. This regular upkeep is the cornerstone of **how to clean a top loader washing machine**

effectively.

Leave the Lid Open

After each wash, prop the lid open for at least an hour to allow moisture to evaporate. A closed lid creates a dark, damp environment perfect for mold. Many modern top loaders even have a lid lock that disengages after a cycle—use that opportunity to air it out.

Use the Right Detergent Amount

Using too much detergent causes buildup inside the machine. Follow the manufacturer's guidelines, and consider using high-efficiency (HE) detergent if your washer is HE-compatible. Excess suds are a major contributor to residue and odors.

Wipe Down After Every Use

Keep a clean cloth near your washer and quickly wipe the lid rim, inside the drum's top edge, and the dispenser area after each load. This 30-second habit prevents mold from taking hold.

WHAT TO AVOID WHEN CLEANING YOUR TOP LOADER

- **Avoid mixing bleach and vinegar** – This produces toxic chlorine gas. Use them in separate cycles (e.g., bleach one

month, vinegar the next).

- **Don't use harsh abrasive cleaners** – They can scratch the drum or lid finish, creating crevices where bacteria hide.
- **Never run a cleaning cycle with clothes inside** – The vinegar or bleach can damage fabric and cause color fading.
- **Avoid overfilling the machine** – When cleaning, use the largest load setting but do not pack the drum with rags—let the water and cleaner circulate freely.

WHEN TO CALL A PROFESSIONAL

If after a thorough cleaning you still notice a strong odor, draining problems, or unusual noises, there may be a mechanical issue. Clogs deep in the drain hose, a faulty pump, or a broken agitator require professional attention. Likewise, if your machine displays

error codes related to drainage or pressure, it's time to consult a technician. Knowing **how to clean a top loader washing machine** covers routine maintenance, but it doesn't replace appliance repair.

CONCLUSION

Keeping your top loader washing machine clean is simple, inexpensive, and incredibly rewarding. By following this step-by-step guide—using vinegar, baking soda, and a little elbow grease—you can eliminate odors, improve performance, and extend the life of your appliance. Make it a habit to leave the lid open, use the correct amount of detergent, and run a deep clean every month. Your clothes will smell fresher, your machine will run more efficiently, and you'll save money on repairs. Now that you know **how to clean a top loader washing machine**, there's no excuse to put it off. Give your washer the care it deserves today.